



Rota Yokogawa - **Flowcenter of Excellence**

Installation Procedure for the “Flow Configurator 3.6”:

SYSTEM REQUIREMENTS:

- Microsoft® .NET Framework 1.1 (will not work with 2.0 only)
- Adobe® Reader®
- Min. 256 MB RAM; 512MB recommended
- Approx. 60MB free hard disc space

Supported Operating Systems:

Windows 2000; Windows XP; Windows Vista (all Versions)

Installation:

1. Be sure you have appropriate permissions to install software! In case of trouble or missing permissions ask your administrator to perform the installation according the following steps. **Please remove all former sizing versions before you start this installation!**
2. Make sure you have the latest service pack and critical updates for the version of Windows® that you are running. To find recent security updates, visit [Windows® Update](#) .
If you have already installed the Microsoft® .NET Framework 1.1-package You can skip items 3 to 5 and continue the installation from item 6.
3. Download the [.NET Framework Version 1.1 Redistributable Package](#) from the Microsoft® Download site and install the package following the instructions given by Microsoft. (Alternatively you can start CD:\Microsoft\1.1\dotnetfx.exe from the CD) Choose the appropriate language of the package corresponding to the language of your Windows® version.
4. Download and install the [Microsoft® .NET Framework 1.1 Service Pack 1](#) from the Microsoft® Download site (or use the file “CD:\Microsoft\1.1\sp1\NDP1.1sp1-KB867460-X86.exe” from the CD) and install the Service Pack following the instructions given by Microsoft. Choose the appropriate language of the package corresponding to the language of your Windows® version.



Rota Yokogawa - **Flowcenter of Excellence**

5. Download and install the [ASP.NET Security Update for Microsoft® .NET Framework 1.1 Service Pack 1](#) from the Microsoft® Download site (or use "CD:\Microsoft\1.1\Update_sp1\NDP1.1sp1-KB886903-X86.exe" from the CD) and install the Security Update following the instructions given by Microsoft. Choose the appropriate language of the package corresponding to the language of your Windows® version.
6. If necessary download and install the [Microsoft® .NET Framework Version 1.1 Language Pack](#) from the Microsoft® Download site and install the Language Pack following the instructions given by Microsoft. Choose the appropriate language of the package corresponding to the language of your Windows® version.
7. Only for Windows® 2000 you have to install „ MDAC_TYP8.EXE“ from the CD ("CD:\Microsoft\MDAC_TYP8.EXE") additionally.
8. You can either download the Flow Configurator Version 3.6 directly from the FCP or order a CD from fcp.info@de.yokogawa.com. After you have downloaded the "Setup.msi"-file, please start it and follow the instructions given.
9. Every user of the installed sizing program must have **modify permissions** for the chosen install path of step 8.
10. You can start the program by double-clicking the icon "**Sizing**" on the desktop.
11. In order to remove the FlowConfigurator simply start "Setup.msi" again and select "Remove".
12. For printing to pdf-files an appropriate Tool is required. A freeware pdf-converter is available at <http://shbox.de/fpxp.htm>